



[Maytag Residential Maytag A200S Washer Parts](#) Parts Diagram 01 - 115-230 VOLT, 50 CYCLE PARTS
[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	202158		Not Available	MOTOR 120-50
2	Y202496			Pulley, Motor
3	211709		Not Available	MOTOR STOP
4	211948			V Belt, Drive Pulley
5	211451			Belt, Pump
6	201408			Capacitor 120-50
7	200977			Solenoid For Water Valve
8	201090			Timer
9	201003			Timer Motor
10	201012		Not Available	ESCAPEMENT FOR TIMER
11	202157	12002352		Motor-Drive
12	Y202496			Pulley, Motor
13	211709		Not Available	MOTOR STOP
14	211948			V Belt, Drive Pulley
15	211451			Belt, Pump
16	201101			Capacitor

17	201099	Not Available	VALVE 240-50
18	201848		Solenoid 240-50
19	201104	Not Available	SOLENOID 240-50
20	201100	Not Available	THERMOGUARD
21	201098	Not Available	TIMER
22	201001	Not Available	TIMER MOTOR 240-50
23	201619		Timer Motor
24	201012	Not Available	ESCAPEMENT FOR TIMER

