



Maytag [Residential Maytag A200S Washer Parts](#) Parts Diagram 05 - ELECTRICAL PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200729			Timer
2	200806			Solenoid
3	200977			Solenoid For Water Valve
4	200996		Not Available	TIMER MOTOR, A
5	201012		Not Available	ESCAPEMENT FOR TIMER
7	201782			Temperature Switch
8	201805	12002351		Motor-Drve
9	201809			Lid Switch
10	201956		Not Available	MOTOR CORD
11	201977		Not Available	WIRE HARNESS
13	202497		Not Available	UNBALANCE LEVER
14	211065			Spring, Index Wheel
15	211251			Screw, Transformer
16	211553		Not Available	SELF CANCEL ROD
17	211605			Bezel, Timer Dial
18	211835		Not Available	CONTROL KNOB - TIMER

