

## Maytag A200S 06 - FRONT VIEW



[Maytag Residential Maytag A200S Washer Parts](#) Parts Diagram 06 - FRONT VIEW  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200555		Not Available	AGITATOR
2	200725		Not Available	HINGE FOR LID
3	200727		Not Available	DIVERter VALVE
4	<a href="#">200729</a>			Timer
5	200746		Not Available	WATER VALVE---NA
6	200996		Not Available	TIMER MOTOR, A
7	201012		Not Available	ESCAPEMENT FOR TIMER
8	201727		Not Available	BASE FRAME WITH PADS
10	<a href="#">201782</a>			Temperature Switch
11	201805	<a href="#">12002351</a>		Motor-Drve
12	<a href="#">201809</a>			Lid Switch
13	201814		Not Available	TOP COVER, PORCELAIN
14	201956		Not Available	MOTOR CORD
15	201977		Not Available	WIRE HARNESS
17	202292		Not Available	CABINET
18	202297		Not Available	CONTROL PANEL

19	202298	Not Available	CONTROL COVER
20	202497	Not Available	UNBALANCE LEVER
21	202497	Not Available	UNBALANCE LEVER
22	204717	Not Available	BUTTON KIT FOR 2-1782
24	<a href="#">210385</a>		Lock Nut For Adjustable Leg
25	210442	Not Available	WASHER NYLON
26	<a href="#">210609</a>		Nylon Washer
27	<a href="#">210684</a>		Foot, Adjustable Leg
28	210865	Not Available	FASTENER
29	210879	Not Available	SCREW, No.8 X 1/2 INCH
30	210995	Not Available	BACK PANEL
31	211062	Not Available	RUBBER BUMPER
32	<a href="#">211065</a>		Spring, Index Wheel
33	211113	Not Available	TRIM MOULDING
34	211114	Not Available	RETAINER FOR TRIM
35	<a href="#">211196</a>		Acorn Nut
36	211225	Not Available	PAD FOR UNBALANCE BUMPER
37	<a href="#">211251</a>		Screw, Transformer
38	<a href="#">211500</a>		Washer, Bracket To Top Cover
39	211501	Not Available	GASKET FOR LID HINGE
40	211586	Not Available	SCREW, No.8 X 7/8 INCH
41	211587	Not Available	SCREW, No.8 X 1/4 INCH
42	<a href="#">211605</a>		Bezel, Timer Dial
43	211738	Not Available	SPRING FASTENER
44	<a href="#">211739</a>		Screw, Cabinet To Base
45	211792	Not Available	PIN
46	211794	Not Available	SCREW-LID SWITCH TO BRACKET
47	211835	Not Available	CONTROL KNOB - TIMER
48	<a href="#">211881</a>		Grommet, Cord Part Not Used-Gas Models Only
49	211970	Not Available	SCREW-TOP COVER TO CABINET
50	212014	Not Available	MEDALLION
51	<a href="#">212027</a>		Timer Dial-Gray
52	212033	Not Available	LID
53	212138	Not Available	FASTENER, PANEL TO TOP COVE
54	212389	Not Available	LENS
55	212394	Not Available	CLIP FOR LAMP
56	213077	Not Available	CAP FOR TIMER KNOB
57	<a href="#">310219</a>		No.10z Fastener
58	Y310632	<a href="#">1163839</a>	Screw
59	310934	<a href="#">22003428</a>	Leg, Adjustable
60	311434	<a href="#">31-1434</a>	Miniman
61	Y311499	<a href="#">W10068260</a>	Screw
62	Y057937	<a href="#">350930</a>	Paint, Pressurized Spray B