



[Maytag Residential Maytag A200S Washer Parts](#) Parts Diagram 08 - MOTOR MOUNT, BASE FRAME & CENTERING SPRS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	200816	6-2008160		Pulley- MO
2	201455			Damper
3	201639			Upper Motor Mount
4	201674		Not Available	LOWER MOTOR MOUNT----NA
5	201698		Not Available	TUB BRACE
6	201727		Not Available	BASE FRAME WITH PADS
7	201805	12002351		Motor-Drive
8	201956		Not Available	MOTOR CORD
9	202608	213737		Shield, Motor
10	202718			Springs, Tension
11	210186	3370225		Screw
12	210587	W10116760		Screw
13	211124			Part Not Used
14	211125			V Belt, Drive Pulley
15	211155			Washer

16	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
17	211335		Damper Pad - Felt
18	211881		Grommet, Cord Part Not Used-Gas Models Only
19	211944		Eyebolts
20	211949		Nut, Adjustment Eyebolt
21	211952	205000	Roller And Spring Kit 4+Spr
22	211953		Centering Spring
23	Y311426	3400029	Nut, Adapter Plate
24	Y015627		Screw- Hex
25	Y052785		Nut, Brace To Damper
26	Y053241		Set Screw, Motor Pulley
27	Y054866	486009	Lockwasher
28	Y055978		Rubber Adhesive, 2 Oz Tube
29	Y055980		Hi-Temp Adhesive, 2 Oz Tube
30	Y056016		Center Seal Grease

