

Maytag A202S 06 - FRONT VIEW



[Maytag Residential Maytag A202S Washer Parts](#) Parts Diagram 06 - FRONT VIEW

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	200555		Not Available	AGITATOR
2	200727		Not Available	DIVERTER VALVE
3	200746		Not Available	WATER VALVE---NA
4	201124		Not Available	UNBALANCE LEVER
5	201747		Not Available	CONTROL PANEL
6	201755		Not Available	FABRIC SWITCH
8	201782			Temperature Switch
9	201807	12002353		Motor-Drve
10	201956		Not Available	MOTOR CORD
11	202055		Not Available	COVER FOR CONTROL PANEL
12	202292		Not Available	CABINET
13	Y202734	215058		Pad, Cabinet Bumper
14	202770	279347		Switch-Lid
16	202794		Not Available	WIRE HARNESS
17	202923			Timer
18	204717		Not Available	BUTTON KIT FOR 2-1782

20	210175		Not Available	WIRE CONNECTOR
21	210385			Lock Nut For Adjustable Leg
22	210442		Not Available	WASHER NYLON
23	210609			Nylon Washer
24	210684			Foot, Adjustable Leg
25	210865		Not Available	FASTENER
26	210866			Nut, Twin Speed
27	210879		Not Available	SCREW, No.8 X 1/2 INCH
28	210995		Not Available	BACK PANEL
29	211065			Spring, Index Wheel
30	211113		Not Available	TRIM MOULDING
31	211114		Not Available	RETAINER FOR TRIM
32	211168	W10139210		Screw, 8-18 X 5/16
33	211251			Screw, Transformer
34	214697			Easy-Grip Knob
35	211500			Washer, Bracket To Top Cover
36	211586		Not Available	SCREW, No.8 X 7/8 INCH
37	211587		Not Available	SCREW, No.8 X 1/4 INCH
38	211605			Bezel, Timer Dial
39	211726			Hinge, Ball Lid
40	211737	248562		Terminal
41	211738		Not Available	SPRING FASTENER
42	211739			Screw, Cabinet To Base
43	211835		Not Available	CONTROL KNOB - TIMER
44	211881			Grommet, Cord Part Not Used- Gas Models Only
45	211970		Not Available	SCREW-TOP COVER TO CABINET
46	212014		Not Available	MEDALLION
47	212027			Timer Dial-Gray
48	212062		Not Available	RECTANGULAR PLUG
49	212073			LID (WHITE)
50	212138		Not Available	FASTENER, PANEL TO TOP COVE
51	212220	213501		Screw, No.6-20 X 1-1/8 Inch
52	212336		Not Available	SCREW, No.8 X 3/4 INCH
53	212628		Not Available	SCREW & WASHER
54	212716			Bumper, Lid
55	212812		Not Available	TOP COVER, PORCELAIN
56	212813			Pin For Lid Switch
57	212814	204968		Plunger And Bracket Assembly--W
58	213077		Not Available	CAP FOR TIMER KNOB
59	310219			No.10z Fastener
60	Y310376			Clip, Door Switch Harness
61	Y310632	1163839		Screw
62	310934	22003428		Leg, Adjustable
63	053759	25-7614		Screw