

Maytag A207 01 - 50 CYCLE CONVERSION LIST



[Maytag Residential Maytag A207 Washer Parts](#) Parts Diagram 01 - 50 CYCLE CONVERSION LIST
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	202160		Not Available	MOTOR 120-50
2	Y202496			Pulley, Motor
3	211948			V Belt, Drive Pulley
4	211451			Belt, Pump
5	201408			Capacitor 120-50
6	211149			Clip, Capacitor
7	203237			No.17 Wire With Terminal
8	204455		Not Available	TIMER 120-50
9	205034			Timer Motor 120-50
10	202159		Not Available	MOTOR 240-50
11	Y202496			Pulley, Motor
12	211948			V Belt, Drive Pulley
13	211451			Belt, Pump
14	201101			Capacitor
15	211149			Clip, Capacitor
16	203365		Not Available	WATER VALVE W/SOLENOIDS

17	203237		No.17 Wire With Terminal
18	204456	Not Available	TIMER 240-50
19	205035		Timer Motor 240-50
20	205131		Switch, Motor External Start
21	205134	Not Available	MOTOR EXTERNAL START SWITCH
22	205140	Not Available	EXTERNAL START SWITCH

