



[Maytag Residential Maytag A207S Washer Parts](#) Parts Diagram 02 - AGITATOR & ACCESSORIES  
[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	203320		Not Available	LINT FILTER - DISPENSER
2	205054		Not Available	AGITATOR
3	212815		Not Available	DISPENSER CUP
4	<a href="#">Y015494</a>			Stop Ring-Agitator Shaft

