



[Maytag Residential Maytag A207S Washer Parts Parts Diagram 03 - BRAKE & CLUTCH ASSEMBLY](#)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y200720	22003441		Bearing, Rear
2	200835			Bearing, Brake Rotor
3	201126	6-2011900		Brake Asse
4	201190	6-2011900		Brake Asse
5	211000			SCREW, BRAKE DRUM (HEX HEAD)
6	211038		Not Available	CAP, OIL RETAINER
7	211039	6-2011900		Brake Asse
8	211041	6-2011900		Brake Asse
9	211042	6-2011900		Brake Asse
10	211043	6-2011900		Brake Asse
11	211045	6-2011900		Brake Asse
12	211059	6-2301530		Pulley
13	211089			Lug, Stop Pulley
14	211090	22003555		Washer, Stop Lug
15	211375	681582		Screw
				TOOL TO DISMANTLE

