



Maytag [Residential Maytag A207S Washer Parts](#) Parts Diagram 11 - POWER UNIT & CENTER ASSEMBLY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200730	<a href="#">22002124</a>		Shaft- Agi
2	200750		Not Available	GEAR CASE COVER
3	200813		Not Available	GEAR CASE COVER ASSEMBLY
4	200824	<a href="#">6-2040130</a>		Tub Bearin
5	201537	<a href="#">6-2095720</a>		Mounting S
6	202521	<a href="#">6-2095720</a>		Mounting S
7	<a href="#">203162</a>			Gear Housing W/Studs And Tube
8	<a href="#">203775</a>			Ctn 10 Auto Trans Lube
9	204012	<a href="#">6-2095720</a>		Mounting S
10	204013	<a href="#">6-2040130</a>		Tub Bearin
11	204437	<a href="#">W10172458</a>		Transmison
12	<a href="#">204967</a>			Gear Kit-Power Fin Agitator
13	210052	<a href="#">7501P061-60</a>		Valve Ove
14	<a href="#">210054</a>			Pinion
15	<a href="#">210179</a>			Retaining Ring

16	<a href="#">210183</a>		Groove Pin
17	<a href="#">210286</a>		Seal
18	<a href="#">210315</a>		Pinion
19	210632	<a href="#">22210632</a>	Gasket
20	201463	Not Available	PITMAN WITH WRIST PIN
21	<a href="#">210690</a>		Seal, Rubber
22	211022	Not Available	BEARING
23	211028	<a href="#">22001586</a>	Deflector, Water
24	211047	<a href="#">6-2110472</a>	Nut- Clamp
25	<a href="#">211089</a>		Lug, Stop Pulley
26	211090	<a href="#">22003555</a>	Washer, Stop Lug
27	<a href="#">211100</a>		Washer, Outer Tub
28	<a href="#">211130</a>		Bearing Liner, Tub Bearing
29	<a href="#">211210</a>		Washer, Clamping Nut
30	211375	<a href="#">681582</a>	Screw
31	211483	<a href="#">6-2114830</a>	Washer- SP
32	<a href="#">211484</a>		Washer, Lug
33	<a href="#">211486</a>		Screw, 3/8-16 X 1/2 Inch
34	<a href="#">211487</a>		Groov-Pin
35	211618	<a href="#">22001423</a>	Set Screw, Mounting Stem
36	211837	Not Available	SPRING FOR TUB SEAL
37	<a href="#">212988</a>		Part Not Used
38	213068	<a href="#">204967</a>	Gear Kit-Power Fin Agitator
39	214276	Not Available	WASHER FOR GEARS
40	Y0A4298	<a href="#">6-0A57420</a>	Seal- Agitator
41	Y014792	<a href="#">6-0A57420</a>	Seal- Agitator
42	<a href="#">Y014827</a>		Washer-Center Shaft
43	<a href="#">Y014839</a>		Collar-Drive Shaft
44	<a href="#">Y015149</a>		Brass Washer-Agitator Seal
45	<a href="#">Y015494</a>		Stop Ring-Agitator Shaft
46	<a href="#">Y015629</a>		Bolt, Grinding Chamber
47	<a href="#">015639</a>		Dowel Pin
48	<a href="#">Y015666</a>		Washer, Retaining -
49	<a href="#">Y015667</a>		Retaining Ring
50	<a href="#">Y015902</a>		Spring For Agitator
51	<a href="#">Y308313</a>		Wire Harness, Main
52	<a href="#">Y038555</a>		Tool-Install Center Shaft
53	<a href="#">Y054867</a>		Washer, Lock
54	<a href="#">Y056016</a>		Center Seal Grease
55	Y056080	<a href="#">6-0560800</a>	Oil

*the laundry company*<sup>®</sup>