

Maytag A207S 12 - REAR VIEW (ORIGINAL & SERIES 01)



[Maytag Residential Maytag A207S Washer Parts](#) Parts Diagram 12 - REAR VIEW (ORIGINAL & SERIES 01)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	203172		Not Available	TOP COVER-WHITE
2	203177	205613		Water Valve
3	203319	22203319		Cabinet
4	204590			Cord, Power
5	205003		Not Available	CONTROL PANEL
6	205192		Not Available	CONTROL PANEL, SUN-GLOW
7	205197		Not Available	CONTROL PANEL KIT, SUN-GLOW
8	210385			Lock Nut For Adjustable Leg
9	210684			Foot, Adjustable Leg
10	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
11	211878		Not Available	PLATE, ACCESS
12	211881			Grommet, Cord Part Not Used-Gas Models Only
13	212276	W10116760		Screw
14	212277			Screw, No.8 X 1/2 Inch

15	212984		Valve Mounting Plate
16	212985	22002924	Plate, Access
17	213009		Not Available CONTROL COVER-WHITE
18	213121	3400111	Screw, 12-14 X 5/8
19	214135		Not Available CLIP, FASTENER
20	214337	96160	Screen
21	214337	96160	Screen
22	214519		LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
23	Y302699	22003428	Leg, Adjustable
24	312620		Screw, Sems

the laundry company[®]

the laundry company[®]

the laundry company[®]