



Maytag [Residential Maytag A208S Washer Parts](#) Parts Diagram 11 - MOTOR MOUNT, BASE FRAME & CENTER SPRINGS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	Y015627			Screw- Hex
2	Y052734			Nut, Carrage Bolts And Bracket
3	Y052785			Nut, Brace To Damper
4	Y053241			Set Screw, Motor Pulley
5	Y054866	486009		Lockwasher
6	Y054867			Washer, Lock
7	200744	W10175939		Bolt
8	200816	6-2008160		Pulley- MO
9	201190	6-2011900		Brake Asse
10	201639			Upper Motor Mount
11	201674		Not Available	LOWER MOTOR MOUNT----NA
12	201807	12002353		Motor-Drve
13	202203	6-2022030		Pump As Pa
14	202677		Not Available	PUMP PULLEY WITH PIN

15	202718		Springs, Tension
16	203274		Base With Damper Pads
17	203725		Damper W/Bolt And Clip
18	203956		Damper Pad Kit
19	204314	Not Available	POLY LUBE - 4 OZ
20	204998	205000	Roller And Spring Kit 4+Spr
21	204999		Poly-Lube Grease, 3.5 Grams
22	205000		Roller And Spring Kit 4+Spr
23	205131		Switch, Motor External Start
25	205140	Not Available	EXTERNAL START SWITCH
26	210385		Lock Nut For Adjustable Leg
27	210684		Foot, Adjustable Leg
28	211038	Not Available	CAP, OIL RETAINER
29	211059	6-2301530	Pulley
30	211089		Lug, Stop Pulley
31	211090	22003555	Washer, Stop Lug
32	211100		Washer, Outer Tub
33	211124		Part Not Used
34	211125		V Belt, Drive Pulley
35	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
36	211375	681582	Screw
37	211880		Screw, HeX Head No.10 X 1/2 Inc
38	211949		Nut, Adjustment Eyebolt
39	212979	Not Available	WASHER, TUB BRACE
40	213007		Xfor Cabinet See Cabinet, Back
41	213054		Centering Spring - 3 Used
42	213073		Washer, Double Brace
43	213100	Not Available	PART NOT USED
44	213120	216416	Bolt, Eye/Centering Spring
45	213121	3400111	Screw, 12-14 X 5/8
46	213325		Clip, Retaining
47	213326		Bolt, Sems Retaining Clip
48	213737		Shield, Motor
49	213846		Guard, Belt
50	Y302699	22003428	Leg, Adjustable
51	Y311426	3400029	Nut, Adapter Plate
52	Y313262	W10116752	Retainer-

the laundry company[®]