



Maytag [Residential Maytag A208S Washer Parts](#) Parts Diagram 16 - TOP COVER UP
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200846			Clamp - Tub Cover
2	201523		Not Available	INNER TUB
3	201765		Not Available	COVER, TUB
4	202515	596669		Clamp, Manifold
5	Y202734	215058		Pad, Cabinet Bumper
6	202770	279347		Switch-Lid
7	203319	22203319		Cabinet
8	203320		Not Available	LINT FILTER - DISPENSER
9	204445			Screw And Fastener Assembly
10	204968			Plunger And Bracket Assembly--W
11	205054		Not Available	AGITATOR
12	205160		Not Available	TOP COVER-WHITE
13	205161	489503		Clamp
14	205218		Not Available	OUTER TUB ASSEMBLY
15	210866			Nut, Twin Speed
16	211223			Bumper, Unbalance

17	211232		Seal, Tub Cover
18	212073		LID (WHITE)
19	212716		Bumper, Lid
20	212815	Not Available	DISPENSER CUP
21	212937	Not Available	BARRIER, MOISTURE
22	212942	22001619	Tube, Water Level Switch
23	213013		Hose, Injector
24	213015		Nozzle, Injector
25	213055	206154	Injector Tube With Seal
26	213718		Plunger, Lid Switch
27	213719	Not Available	LEVER, UNBALANCE
28	213720		Spring, Lid Switch
29	214135	Not Available	CLIP, FASTENER
30	214376	22002331	Spacer, Front Panel
31	214436		Gasket
32	214437	215577	Bleach Inlet White
33	214495		Tube, Inlet To Tub
34	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx

