



[Maytag Residential Maytag A210 Washer Parts Parts Diagram 01 - 50HZ PARTS](#)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	202158		Not Available	MOTOR 120-50
2	Y202496			Pulley, Motor
3	211948			V Belt, Drive Pulley
4	211451			Belt, Pump
5	201408			Capacitor 120-50
6	205613			Water Valve
7	203237			No.17 Wire With Terminal
8	205776		Not Available	TIMER 120-50
9	202157	12002352		Motor-Drive
10	Y202496			Pulley, Motor
11	211948			V Belt, Drive Pulley
12	211451			Belt, Pump
13	201101			Capacitor
14	211149			Clip, Capacitor
15	Y205684		Not Available	WATER VALVE 240-50
16	203237			No.17 Wire With Terminal

