


Maytag A211S 02 - CABINET



16

Maytag Residential Maytag A211S Washer Parts Parts Diagram 02 - CABINET
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	212276	W10116760		Screw
2	Y313561			Screw---NA
3	Y013783			Washer, Inlet Hose
4	202860			Inlet Hose Assembly
5	200961	12001413		Strainer And Washer Kit
6	215279	22003410		Hose, Drain
7	200461	285655		Clamp, Hose
8	Y014874			Screw, Idler Arm And Sleeve
9	214764	208847		Elbow
10	214765			Gasket, Siphon Break
11	206638			Siphon Break
12	200461	285655		Clamp, Hose
13	215058			Pad, Cabinet Bumper
14	214767	22001448		Hose, Pump
15	214376	22002331		Spacer, Front Panel
16	212982	22001650		Fastener, Spring

17	204439		Screw And Fstner Assembly
18	213846		Guard, Belt
19	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
20	212998	Not Available	PANEL, FRONT (WHT)
21	211878	Not Available	PLATE, ACCESS
22	213122	27001200	Screw
23	213007		Xfor Cabinet See Cabinet, Back
24	213121	3400111	Screw, 12-14 X 5/8
25	203319	22203319	Cabinet
26	214337	96160	Screen
27	205613		Water Valve
28	201575		Clamp, Hose
29	214812	22002361	Bracket, Water Valve
30	206103		Capacitor Kit
31	203237		No.17 Wire With Terminal
32	Y200832		Capacitor
33	211149		Clip, Capacitor

