



Maytag [Residential Maytag A21CA Washer Parts](#) Parts Diagram 06 - CA CONTROL CENTER
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	NLA		Not Available	MOTOR, TIMER
003	NLA		Not Available	STRAP, MOUNTING
004	NLA		Not Available	CASE, OUTER (WHT)
005	NLA		Not Available	TIMER
006	NLA		Not Available	CENTER, CONTROL (WHT)
007	204973			Motor, Timer
008	NLA		Not Available	COVER, CONTROL (WHT)
009	NLA		Not Available	PANEL, CONTROL (W/LENS)
010	NLA		Not Available	MARKER, BUTTON
011	211065			Spring, Index Wheel
012	NLA		Not Available	CAP, KNOB
013	211093		Not Available	RETAINER
014	211120			Knob, Timer
015	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
016	211251			Screw, Transformer

017	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
018	212276	W10116760	Screw
019	212277		Screw, No.8 X 1/2 Inch
020	NLA	Not Available	DOOR, ACCESS
021	NLA	Not Available	GASKET, CONTROL CENTER
022	213949		Screw, No.8-18 X 5/16 Inch
023	214610		Bumper, Lid
024	910309		Washer, Mounting Strap

