


Maytag A21CM 06 - CM CONTROL CENTER

14

SPECIFY COLOR IF OTHER THAN WHITE

MODELS A21-A22

CM CONTROL CENTER



Maytag [Residential Maytag A21CM Washer Parts](#) Parts Diagram 06 - CM CONTROL CENTER

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	NLA		Not Available	MOTOR, TIMER
003	205415	279347		Switch-Lid
004	203188		Not Available	TIMER ACCESS DOOR (WHT)
005	NLA		Not Available	WASHER SLIDES ACTUATOR KIT
006	NLA		Not Available	STRAP, MOUNTING
007	203761			DOOR, ACCESS (WHT)
008	203761			DOOR, ACCESS (WHT)
009	NLA		Not Available	SWITCH HARNESS, TIMER
010	NLA		Not Available	LATCH, ANTI-INERTIA
011	NLA		Not Available	RELAY (240-50)
012	NLA		Not Available	BOX, COIN (WHT)
013	NLA		Not Available	WIRE HARNESS, MAIN
014	204577		Not Available	TIMER WITH KNOB AND PIN
015	NLA		Not Available	CENTER, CONTROL (WHT)

016	204973		Motor, Timer
017	NLA	Not Available	COUNTER KIT W/ACTUATOR
018	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
019	NLA	Not Available	FASTENER
020	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
021	212276	W10116760	Screw
022	NLA	Not Available	GASKET, CONTROL CENTER
023	213035		Bolt, Locking
024	213501		Screw, No.6-20 X 1-1/8 Inch
025	NLA	Not Available	SPRING WASHER, LOCK
026	212951		Screw, No.6-32 X 1/4 Inch
027	NLA	Not Available	RETURN SPRING, TENSION LEVER
028	NLA	Not Available	LEVER ARM, SWITCH
029	NLA	Not Available	MOUNTING BRACKET, TIMER
030	NLA	Not Available	CASE, OUTER (WHT)
031	NLA	Not Available	SCREW, RETAINER
032	910181		Lockwasher, Terminal Block

