


Maytag A26CA 05 - TRANSMISSION (SERIES 00)

ALL LEVELS

TRANSMISSION  
PRIOR TO SERIES 10



Maytag Residential Maytag A26CA Washer Parts Parts Diagram 05 - TRANSMISSION (SERIES 00)  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">Y014827</a>			Washer-Center Shaft
002	<a href="#">Y014839</a>			Collar-Drive Shaft
003	<a href="#">Y015629</a>			Bolt, Grinding Chamber
004	NLA		Not Available	DOWEL PIN
005	<a href="#">Y015902</a>			Spring For Agitator
006	Y052740	<a href="#">62739</a>		Nut, Lock
007	Y056080	<a href="#">6-0560800</a>		Oil
008	200730	<a href="#">22002124</a>		Shaft- Agi
009	NLA		Not Available	GEAR CASE COVER ASSEMBLY
010	NLA		Not Available	PITMAN WITH WRIST PIN
011	NLA		Not Available	PART NOT USED
012	NLA		Not Available	HOUSING, GEAR
013	<a href="#">204967</a>			Gear Kit-Power Fin Agitator
014	NLA		Not Available	COUNTERWEIGHT
015	206602	<a href="#">207843</a>		Lip Seal Repair Kit
016	<a href="#">210054</a>			Pinion

017	NLA		Not Available	LOCK WASHER
018	<a href="#">210183</a>			Groove Pin
019	<a href="#">210315</a>			Pinion
020	210632	<a href="#">22210632</a>		Gasket
021	NLA		Not Available	SEGMENT
022	<a href="#">210690</a>			Seal, Rubber
023	<a href="#">211089</a>			Lug, Stop Pulley
024	211090	<a href="#">22003555</a>		Washer, Stop Lug
025	211375	<a href="#">681582</a>		Screw
026	211483	<a href="#">6-2114830</a>		Washer- SP
027	<a href="#">211484</a>			Washer, Lug
028	<a href="#">211486</a>			Screw, 3/8-16 X 1/2 Inch
029	NLA		Not Available	GROOV-PIN
030	<a href="#">212988</a>			Part Not Used
031	<a href="#">213044</a>			Shaft, Center

