


Maytag A282 08 - TRANSMISSION-ORBITAL



24

Maytag Residential Maytag A282 Washer Parts Parts Diagram 08 - TRANSMISSION-ORBITAL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	206708	6-2097790		Transmison
2	207153	6-2097820		Kit- Shaft
3	206713	6-2067130		Gear- Beve
4	215581			Spring, Agitator Shaft
5	206685	6-2066850		Yoke
6	206628			Cover, Transmission
7	215417		Not Available	SCREW, TRANSMISSION COVER
8	215415		Not Available	COLLAR, LOWER
9	215401	W10221114		Pinion
10	215395			Plate, Clutch
11	211483	6-2114830		Washer- SP
12	Y206629			Pin, Collar
13	215411	12001451		Ctr Shaft W/Collar Andkeeper-Sha
14	211059	6-2301530		Pulley
15	211089			Lug, Stop Pulley

16	211375	681582	Screw
17	211090	22003555	Washer, Stop Lug
18	206602	207843	Lip Seal Repair Kit
19	215394		Washer, Bevel Gear
20	206625	6-2097790	Transmison
21	Y058700	675652	Adhesive
22	210690		Seal, Rubber
25	215733		Dispensing Cup
26	Y207427		Lint Filter Shallow
27	207538		Agitator W/Lock Screw
28	206478	Not Available	SCREW & WASHER FOR AGITATOR


the laundry company[®]


the laundry company[®]


the laundry company[®]