

Maytag A300S 07 - FRONT VIEW



[Maytag Residential Maytag A300S Washer Parts](#) Parts Diagram 07 - FRONT VIEW
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200555		Not Available	AGITATOR
2	200725		Not Available	HINGE FOR LID
3	200727		Not Available	DIVERter VALVE
4	200746		Not Available	WATER VALVE----NA
5	201727		Not Available	BASE FRAME WITH PADS
7	201754		Not Available	PRESSURE SWITCH
8	201759			Timer
10	201782			Temperature Switch
11	201805	12002351		Motor-Drve
12	201809			Lid Switch
13	201814		Not Available	TOP COVER, PORCELAIN
14	201956		Not Available	MOTOR CORD
16	202248		Not Available	MAJOR WIRE HARNESS
17	202292		Not Available	CABINET
18	202298		Not Available	CONTROL COVER
19	202497		Not Available	UNBALANCE LEVER

20	Y202734	215058		Pad, Cabinet Bumper
21	202842		Not Available	CONTROL PANEL
22	204716		Not Available	BUTTON KIT FOR 2-1754
23	204717		Not Available	BUTTON KIT FOR 2-1782
25	210385			Lock Nut For Adjustable Leg
26	210442		Not Available	WASHER NYLON
27	210609			Nylon Washer
28	210684			Foot, Adjustable Leg
29	210865		Not Available	FASTENER
30	210879		Not Available	SCREW, No.8 X 1/2 INCH
31	210995		Not Available	BACK PANEL
32	211062		Not Available	RUBBER BUMPER
33	211065			Spring, Index Wheel
34	211113		Not Available	TRIM MOULDING
35	211114		Not Available	RETAINER FOR TRIM
36	211168	W10139210		Screw, 8-18 X 5/16
37	211223			Bumper, Unbalance
38	211225		Not Available	PAD FOR UNBALANCE BUMPER
39	211251			Screw, Transformer
40	211500			Washer, Bracket To Top Cover
41	211501		Not Available	GASKET FOR LID HINGE
42	211586		Not Available	SCREW, No.8 X 7/8 INCH
43	211587		Not Available	SCREW, No.8 X 1/4 INCH
44	211605			Bezel, Timer Dial
45	211703		Not Available	DRAIN HOSE
46	211738		Not Available	SPRING FASTENER
47	211739			Screw, Cabinet To Base
48	211792		Not Available	PIN
49	211794		Not Available	SCREW-LID SWITCH TO BRACKET
50	211835		Not Available	CONTROL KNOB - TIMER
51	211881			Grommet, Cord Part Not Used- Gas Models Only
52	211970		Not Available	SCREW-TOP COVER TO CABINET
54	212012		Not Available	TIMER DIAL
55	312014	4391990		Switch-Inf
56	212033		Not Available	LID
57	212062		Not Available	RECTANGULAR PLUG
58	212138		Not Available	FASTENER, PANEL TO TOP COVE
59	212389		Not Available	LENS
60	212394		Not Available	CLIP FOR LAMP
61	213077		Not Available	CAP FOR TIMER KNOB
62	310219			No.10z Fastener
63	Y310632	1163839		Screw
64	310934	22003428		Leg, Adjustable
65	311434	31-1434		Miniman
66	Y311499	W10068260		Screw
67	Y057937	350930		Paint, Pressurized Spray B