


# Maytag A308 07 - TRANSMISSION



Maytag [Residential Maytag A308 Washer Parts](#) Parts Diagram 07 - TRANSMISSION  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">Y014827</a>			Washer-Center Shaft
2	<a href="#">Y014839</a>			Collar-Drive Shaft
3	<a href="#">Y015629</a>			Bolt, Grinding Chamber
4	<a href="#">015639</a>			Dowel Pin
5	<a href="#">Y015902</a>			Spring For Agitator
6	Y052740	<a href="#">62739</a>		Nut, Lock
7	Y056080	<a href="#">6-0560800</a>		Oil
8	200730	<a href="#">22002124</a>		Shaft-Agi
9	200813		Not Available	GEAR CASE COVER ASSEMBLY
10	201463		Not Available	PITMAN WITH WRIST PIN
11	203193		Not Available	GEAR HOUSING W/STUDS & TUBE
12	203438	<a href="#">W10172457</a>		Transmison
13	<a href="#">204967</a>			Gear Kit-Power Fin Agitator
14	<a href="#">205811</a>			Counterweight
15	<a href="#">210054</a>			Pinion

16	<a href="#">210172</a>		Lock Washer
17	<a href="#">210179</a>		Retaining Ring
18	<a href="#">210183</a>		Groove Pin
19	<a href="#">210286</a>		Seal
20	<a href="#">210315</a>		Pinion
21	210632	<a href="#">22210632</a>	Gasket
22	<a href="#">210670</a>		Segment
23	<a href="#">210690</a>		Seal, Rubber
24	<a href="#">211089</a>		Lug, Stop Pulley
25	211090	<a href="#">22003555</a>	Washer, Stop Lug
26	211375	<a href="#">681582</a>	Screw
27	211483	<a href="#">6-2114830</a>	Washer- SP
28	<a href="#">211484</a>		Washer, Lug
29	<a href="#">211486</a>		Screw, 3/8-16 X 1/2 Inch
30	<a href="#">211487</a>		Groov-Pin
31	<a href="#">213044</a>		Shaft, Center
32	214276	Not Available	WASHER FOR GEARS

