



Maytag Residential Maytag A310 Washer Parts Parts Diagram 07 - TRANSMISSIONS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y014827			Washer-Center Shaft
2	Y014839			Collar-Drive Shaft
3	Y015629			Bolt, Grinding Chamber
4	015639			Dowel Pin
5	Y015902			Spring For Agitator
6	Y052740	62739		Nut, Lock
7	Y056080	6-0560800		Oil
8	200730	22002124		Shaft- Agi
9	200813		Not Available	GEAR CASE COVER ASSEMBLY
10	201463		Not Available	PITMAN WITH WRIST PIN
11	203162			Gear Housing W/Studs And Tube
13	203383	W10172458		Transmison
14	204967			Gear Kit-Power Fin Agitator
15	205811			Counterweight
16	210054			Pinion

17	210172		Lock Washer
18	210179		Retaining Ring
19	210183		Groove Pin
20	210286		Seal
21	210315		Pinion
22	210632	22210632	Gasket
23	210670		Segment
24	210690		Seal, Rubber
25	211089		Lug, Stop Pulley
26	211090	22003555	Washer, Stop Lug
28	211375	681582	Screw
29	211483	6-2114830	Washer- SP
30	211484		Washer, Lug
31	211486		Screw, 3/8-16 X 1/2 Inch
32	211487		Groov-Pin
33	212988		Part Not Used
35	213068	204967	Gear Kit-Power Fin Agitator
36	214276	Not Available	WASHER FOR GEARS

