



[Maytag Residential Maytag A406S Washer Parts Parts Diagram 02 - AGITATOR & ACCESSORIES](#)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	203265			Lint Filter-Dispenser
2	203323	22004085		Large Agitator
3	211654		Not Available	O RING SEAL
4	212815		Not Available	DISPENSER CUP
5	213017		Not Available	SHROUD FOR ORIGINAL AGITATOR
6	910186	99002757		Screw
7	Y015494			Stop Ring-Agitator Shaft
8	0A4731		Not Available	SPLINE