



[Maytag Residential Maytag A406S Washer Parts](#) Parts Diagram 11 - POWER UNIT & CENTER ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200730	22002124		Shaft- Agi
2	200750		Not Available	GEAR CASE COVER
3	200813		Not Available	GEAR CASE COVER ASSEMBLY
4	200824	6-2040130		Tub Bearin
5	201537	6-2095720		Mounting S
6	202521	6-2095720		Mounting S
7	203193		Not Available	GEAR HOUSING W/STUDS & TUBE
8	203723	W10172457		Transmison
9	204012	6-2095720		Mounting S
10	204013	6-2040130		Tub Bearin
11	204967			Gear Kit-Power Fin Agitator
12	210052	7501P061-60		Valve Ove
13	210054			Pinion
14	210179			Retaining Ring
15	210183			Groove Pin

16	210286		Seal
17	210315		Pinion
18	210632	22210632	Gasket
19	210690		Seal, Rubber
20	211022	Not Available	BEARING
21	211028	22001586	Deflector, Water
22	211047	6-2110472	Nut- Clamp
23	211089		Lug, Stop Pulley
24	211090	22003555	Washer, Stop Lug
25	211100		Washer, Outer Tub
26	211130		Bearing Liner, Tub Bearing
27	211210		Washer, Clamping Nut
28	211375	681582	Screw
29	211483	6-2114830	Washer- SP
30	211484		Washer, Lug
31	211486		Screw, 3/8-16 X 1/2 Inch
32	211487		Groov-Pin
33	211618	22001423	Set Screw, Mounting Stem
34	211837	Not Available	SPRING FOR TUB SEAL
35	213044		Shaft, Center
36	213068	204967	Gear Kit-Power Fin Agitator
37	214276	Not Available	WASHER FOR GEARS
38	Y0A4298	6-0A57420	Seal- Agitator
39	Y014792	6-0A57420	Seal- Agitator
40	Y014827		Washer-Center Shaft
41	Y014839		Collar-Drive Shaft
42	Y015149		Brass Washer-Agitator Seal
43	Y015494		Stop Ring-Agitator Shaft
44	Y015629		Bolt, Grinding Chamber
45	015639		Dowel Pin
46	Y015666		Washer, Retaining -
47	Y015667		Retaining Ring
48	Y015902		Spring For Agitator
49	038313	22038313	Wrench, Spanner
50	Y038555		Tool-Install Center Shaft
51	Y054867		Washer, Lock
52	Y056016		Center Seal Grease
53	Y056080	6-0560800	Oil
54	201463	Not Available	PITMAN WITH WRIST PIN
55	203775		Ctn 10 Auto Trans Lube