



Maytag [Residential Maytag A406S Washer Parts](#) Parts Diagram 12 - REAR VIEW

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	203172		Not Available	TOP COVER-WHITE
2	203177	<a href="#">205613</a>		Water Valve
3	203319	<a href="#">22203319</a>		Cabinet
4	205197		Not Available	CONTROL PANEL KIT, SUN-GLOW
5	<a href="#">204590</a>			Cord, Power
6	<a href="#">210385</a>			Lock Nut For Adjustable Leg
7	<a href="#">210684</a>			Foot, Adjustable Leg
8	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
9	211878		Not Available	PLATE, ACCESS
10	<a href="#">211881</a>			Grommet, Cord Part Not Used-Gas Models Only
11	212276	<a href="#">W10116760</a>		Screw
12	<a href="#">212277</a>			Screw, No.8 X 1/2 Inch
13	<a href="#">212984</a>			Valve Mounting Plate
14	212985	<a href="#">22002924</a>		Plate, Access

15	213009		Not Available	CONTROL COVER-WHITE
16	213121	<a href="#">3400111</a>		Screw, 12-14 X 5/8
17	214135		Not Available	CLIP, FASTENER
18	214337	<a href="#">96160</a>		Screen
19	Y302699	<a href="#">22003428</a>		Leg, Adjustable
20	<a href="#">312620</a>			Screw, Sems

