



[Maytag Residential Maytag A408S Washer Parts](#) Parts Diagram 11 - MOTOR SWITCHES
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	205132		Not Available	SWITCH, MOTOR EXTERNAL START No.201664-14,205463-4 & 201800-4
2	205133		Not Available	(PROD. IDNo. 2-1664-8 & 2-5463)
3	205139		Not Available	EXTERNAL START SWITCH

