


Maytag A410 07 - TRANSMISSIONS



Maytag Residential Maytag A410 Washer Parts Parts Diagram 07 - TRANSMISSIONS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y014827			Washer-Center Shaft
2	Y014839			Collar-Drive Shaft
3	Y015629			Bolt, Grinding Chamber
4	015639			Dowel Pin
5	Y015902			Spring For Agitator
6	Y052740	62739		Nut, Lock
7	Y056080	6-0560800		Oil
8	200730	22002124		Shaft- Agi
9	200813		Not Available	GEAR CASE COVER ASSEMBLY
10	201463		Not Available	PITMAN WITH WRIST PIN
11	203162			Gear Housing W/Studs And Tube
12	203193		Not Available	GEAR HOUSING W/STUDS & TUBE
13	203383	W10172458		Transmison
14	203438	W10172457		Transmison

15	204967		Gear Kit-Power Fin Agitator
16	205811		Counterweight
17	210054		Pinion
18	210172		Lock Washer
19	210179		Retaining Ring
20	210183		Groove Pin
21	210286		Seal
22	210315		Pinion
23	210632	22210632	Gasket
24	210670		Segment
25	210690		Seal, Rubber
26	211089		Lug, Stop Pulley
27	211090	22003555	Washer, Stop Lug
28	211375	681582	Screw
29	211483	6-2114830	Washer- SP
30	211484		Washer, Lug
31	211486		Screw, 3/8-16 X 1/2 Inch
32	211487		Groov-Pin
33	212988		Part Not Used
34	213044		Shaft, Center
35	213068	204967	Gear Kit-Power Fin Agitator
36	214276		Not Available WASHER FOR GEARS

