


Maytag A412 04 - CONTROL PANEL (A412)



Maytag Residential Maytag A412 Washer Parts Parts Diagram 04 - CONTROL PANEL (A412)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	205033	22205033		Motor- Tim
2	205410		Not Available	TIMER MOTOR 120-60
3	206216			Water Temperature Switch
4	206220		Not Available	WATER LEVEL SWITCH
5	206563		Not Available	CONTROL PANEL
6	206686			Timer
7	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
8	211065			Spring, Index Wheel
9	211168	W10139210		Screw, 8-18 X 5/16
10	211605			Bezel, Timer Dial
11	213117	67006908		Screw, Ice Rack
12	213966	3400014		Screw
13	214815			End Cap F/Control Panel-LH
14	214816			End Cap F/Control Panel-RH
15	214818			Back Up Plate

16	214872		Panel, End Cap Note, Nut, Lamp Holder
17	214894		Fastener, End Cap
18	214897		Pad, Control Panel
19	215161	22001571	Bezel, Timer Dial
20	215162		Timer Knob
21	215164	Not Available	CAP FOR KNOB

