

## Maytag A50 20 - FRONT VIEW



[Maytag Residential Maytag A50 Washer Parts](#) Parts Diagram 20 - FRONT VIEW  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	211194		Not Available	LOCK WASHER
2	<a href="#">211252</a>			Screw, Ground Wire
3	<a href="#">250005</a>			Timer
4	<a href="#">250079</a>			Lid For Spinner With Pins
5	250080		Not Available	LID FOR WASHER WITH PINS
6	251009		Not Available	HINGE PIN FOR LIDS
7	<a href="#">251010</a>			Knob For Timer
8	<a href="#">251011</a>			Knob For Drain Selector
9	251051		Not Available	TOP COVER
10	251058		Not Available	ACCESS PANEL-WHITE
11	Y251081		Not Available	RETAINER FOR LATCH
12	<a href="#">251082</a>			Lid Latch
13	<a href="#">251129</a>			Screw-Top Cover, Front
14	251186		Not Available	SCREW-TRIM STRIP TO CABINET
15	251214		Not Available	WEDGE

16	251249	Not Available	RETAINER FOR WIRE HARNESS
17	302887	Not Available	CASTERS W/SCREWS SET OF 4
18	302888	Not Available	CASTER WITH SCREW, SINGLE
19	<a href="#">Y310376</a>		Clip, Door Switch Harness
20	<a href="#">310557</a>		Washer
21	Y310632	<a href="#">1163839</a>	Screw
22	312523	Not Available	TRIM STRIP FOR FRONT PANEL
23	810095	<a href="#">211410</a>	Screw, HeX Head No.8 X 3/8 Inch

