



[Maytag Residential Maytag A500S Washer Parts](#) Parts Diagram 01 - 115-230 VOLT, 50 CYCLE PARTS  
[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	202160		Not Available	MOTOR 120-50
2	<a href="#">Y202496</a>			Pulley, Motor
3	211709		Not Available	MOTOR STOP
4	<a href="#">211948</a>			V Belt, Drive Pulley
5	<a href="#">211451</a>			Belt, Pump
6	<a href="#">201408</a>			Capacitor 120-50
7	<a href="#">211149</a>			Clip, Capacitor
8	201909		Not Available	TIMER
9	201911		Not Available	TIMER
10	<a href="#">201003</a>			Timer Motor
11	202208		Not Available	ESCAPEMENT FOR TIMER
12	202159		Not Available	MOTOR 240-50
13	<a href="#">Y202496</a>			Pulley, Motor
14	211709		Not Available	MOTOR STOP
15	<a href="#">211948</a>			V Belt, Drive Pulley
16	<a href="#">211451</a>			Belt, Pump

17	<a href="#">201101</a>		Capacitor
18	201099	Not Available	VALVE 240-50
19	<a href="#">211149</a>		Clip, Capacitor
20	<a href="#">201848</a>		Solenoid 240-50
21	201104	Not Available	SOLENOID 240-50
22	201910	Not Available	TIMER
23	201912	Not Available	TIMER
24	201001	Not Available	TIMER MOTOR 240-50
25	202208	Not Available	ESCAPEMENT FOR TIMER

