



[Maytag Residential Maytag A502 Washer Parts](#) Parts Diagram 01 - 115-230 VOLT, 50 CYCLE PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	202160		Not Available	MOTOR 120-50
2	<a href="#">Y202496</a>			Pulley, Motor
3	211709		Not Available	MOTOR STOP
4	<a href="#">211948</a>			V Belt, Drive Pulley
5	<a href="#">211451</a>			Belt, Pump
6	<a href="#">201408</a>			Capacitor 120-50
7	202993		Not Available	TIMER 120-50
9	203082		Not Available	TIMER MOTOR 120-50
10	<a href="#">211149</a>			Clip, Capacitor
11	202159		Not Available	MOTOR 240-50
12	<a href="#">Y202496</a>			Pulley, Motor
13	211709		Not Available	MOTOR STOP
14	<a href="#">211948</a>			V Belt, Drive Pulley
15	<a href="#">211451</a>			Belt, Pump
16	<a href="#">201101</a>			Capacitor
17	<a href="#">201848</a>			Solenoid 240-50

18	201104	Not Available	SOLENOID 240-50
19	202994	Not Available	TIMER 240-50
21	203083	Not Available	TIMER MOTOR 240-50
22	<a href="#">211149</a>		Clip, Capacitor

