



[Maytag Residential Maytag A502 Washer Parts](#) Parts Diagram 05 - ELECTRICAL PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200046		Not Available	CONNECTOR, FEMALE
3	<a href="#">200977</a>			Solenoid For Water Valve
4	201754		Not Available	PRESSURE SWITCH
5	201755		Not Available	FABRIC SWITCH
6	<a href="#">201781</a>			Temperature Switch
8	201807	<a href="#">12002353</a>		Motor-Drve
9	<a href="#">Y201808</a>			Converter
10	201956		Not Available	MOTOR CORD
11	202312		Not Available	PILOT LAMP
12	202497		Not Available	UNBALANCE LEVER
13	202770	<a href="#">279347</a>		Switch-Lid
14	<a href="#">202772</a>			Timer
16	202787	<a href="#">203174</a>		Timer Dial
19	202793		Not Available	MAJOR WIRE HARNESS
20	203081		Not Available	TIMER MOTOR
21	203084		Not Available	ESCAPEMENT FOR TIMER

22	204716	Not Available	BUTTON KIT FOR 2-1754
24	204721	Not Available	BUTTON KIT
25	204722	Not Available	BUTTON KIT FOR 2-1781
26	210175	Not Available	WIRE CONNECTOR
27	210442	Not Available	WASHER NYLON
28	<a href="#">211065</a>		Spring, Index Wheel
29	211168	<a href="#">W10139210</a>	Screw, 8-18 X 5/16
30	<a href="#">211223</a>		Bumper, Unbalance
31	211225	Not Available	PAD FOR UNBALANCE BUMPER
32	<a href="#">211251</a>		Screw, Transformer
33	211586	Not Available	SCREW, No.8 X 7/8 INCH
34	<a href="#">211605</a>		Bezel, Timer Dial
35	211737	<a href="#">248562</a>	Terminal
36	211835	Not Available	CONTROL KNOB - TIMER
37	212220	<a href="#">213501</a>	Screw, No.6-20 X 1-1/8 Inch
38	212336	Not Available	SCREW, No.8 X 3/4 INCH
39	212389	Not Available	LENS
40	212394	Not Available	CLIP FOR LAMP
41	<a href="#">212813</a>		Pin For Lid Switch
42	212814	<a href="#">204968</a>	Plunger And Bracket Assembly--W
43	213077	Not Available	CAP FOR TIMER KNOB

