

Maytag A502S 07 - FRONT VIEW



[Maytag Residential Maytag A502S Washer Parts](#) Parts Diagram 07 - FRONT VIEW
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	201379		Not Available	AGITATOR - BLACK
2	201754		Not Available	PRESSURE SWITCH
3	201755		Not Available	FABRIC SWITCH
5	201782			Temperature Switch
6	201807	12002353		Motor-Drve
7	202292		Not Available	CABINET
8	202298		Not Available	CONTROL COVER
9	202312		Not Available	PILOT LAMP
10	Y202734	215058		Pad, Cabinet Bumper
11	202770	279347		Switch-Lid
13	202773		Not Available	TIMER
15	202788		Not Available	TIMER DIAL
16	202792		Not Available	MAJOR WIRE HARNESS
18	202842		Not Available	CONTROL PANEL
19	203320		Not Available	LINT FILTER - DISPENSER
20	204716		Not Available	BUTTON KIT FOR 2-1754

21	204717	Not Available	BUTTON KIT FOR 2-1782
23	210385		Lock Nut For Adjustable Leg
24	210442	Not Available	WASHER NYLON
25	210609		Nylon Washer
26	210684		Foot, Adjustable Leg
27	210865	Not Available	FASTENER
28	210866		Nut, Twin Speed
29	210879	Not Available	SCREW, No.8 X 1/2 INCH
30	210995	Not Available	BACK PANEL
31	211065		Spring, Index Wheel
32	211113	Not Available	TRIM MOULDING
33	211114	Not Available	RETAINER FOR TRIM
34	211168	W10139210	Screw, 8-18 X 5/16
35	211223		Bumper, Unbalance
36	211225	Not Available	PAD FOR UNBALANCE BUMPER
37	214697		Easy-Grip Knob
38	211251		Screw, Transformer
39	211500		Washer, Bracket To Top Cover
40	211586	Not Available	SCREW, No.8 X 7/8 INCH
41	211587	Not Available	SCREW, No.8 X 1/4 INCH
42	211605		Bezel, Timer Dial
43	211613	Not Available	CAP, KNOB
44	211726		Hinge, Ball Lid
45	211738	Not Available	SPRING FASTENER
46	211739		Screw, Cabinet To Base
47	211835	Not Available	CONTROL KNOB - TIMER
48	211970	Not Available	SCREW-TOP COVER TO CABINET
49	212014	Not Available	MEDALLION
50	212073		LID (WHITE)
51	212138	Not Available	FASTENER, PANEL TO TOP COVE
52	212220	213501	Screw, No.6-20 X 1-1/8 Inch
53	212336	Not Available	SCREW, No.8 X 3/4 INCH
54	212389	Not Available	LENS
55	212394	Not Available	CLIP FOR LAMP
56	212628	Not Available	SCREW & WASHER
57	212716		Bumper, Lid
58	212812	Not Available	TOP COVER, PORCELAIN
59	212813		Pin For Lid Switch
60	212814	204968	Plunger And Bracket Assembly--W
61	212815	Not Available	DISPENSER CUP
62	213077	Not Available	CAP FOR TIMER KNOB
63	310219		No.10z Fastener
64	Y310632	1163839	Screw
65	310934	22003428	Leg, Adjustable
66	053759	25-7614	Screw
67	Y057937	350930	Paint, Pressurized Spray B