


Maytag A510S 06 - TOP COVER, CONSOLE & LID SWITCH



Maytag Residential Maytag A510S Washer Parts Parts Diagram 06 - TOP COVER, CONSOLE & LID SWITCH
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	205997			Non-Bleach Conversion Kit
2	Y201808			Converter
3	204445			Screw And Fastener Assembly
4	204968			Plunger And Bracket Assembly--W
5	205056	204590		Cord, Power
6	205415	279347		Switch-Lid
7	205538		Not Available	TOP COVER-WHITE
9	205635			Console
12	205821		Not Available	MAIN WIRE HARNESS
16	205915		Not Available	SUDS SAVE HARNESS
17	210186	3370225		Screw
18	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
NI	211500			Washer, Bracket To Top Cover
20	211737	248562		Terminal
21	211726			Hinge, Ball Lid

22	211881		Grommet, Cord Part Not Used-Gas Models Only
23	212073		LID (WHITE)
27	212716		Bumper, Lid
28	213718		Plunger, Lid Switch
29	213720		Spring, Lid Switch
30	214805		Pin For Unbalance Lever
31	214804		Unbalance Lever
32	214813	Not Available	LEVER FOR LID SWITCH
33	214884	213501	Screw, No.6-20 X 1-1/8 Inch
34	214898		Cover For Lid Switch
36	215075		Fastener, Control Panel To Console
37	214987		Moisture Barrier For Switch
38	301548		Clamp, Ground Wire
NI	Y313559		Screw
"	911267		Screw, Pump Cover
"	311155		Ground Wire And Clamp
"	410635		Fastener
"	Y312140		Wire Connector
"	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx

