


Maytag A511S 06 - TOP COVER, CONSOLE & LID SWITCH



Maytag Residential Maytag A511S Washer Parts Parts Diagram 06 - TOP COVER, CONSOLE & LID SWITCH
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	205997			Non-Bleach Conversion Kit
2	Y201808			Converter
3	204445			Screw And Fastener Assembly
4	204968			Plunger And Bracket Assembly--W
5	205056	204590		Cord, Power
6	205415	279347		Switch-Lid
7	205538		Not Available	TOP COVER-WHITE
10	205635			Console
13	205815		Not Available	MAIN WIRE HARNESS
14	205915		Not Available	SUDS SAVE HARNESS
15	210186	3370225		Screw
16	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
17	211500			Washer, Bracket To Top Cover
18	211726			Hinge, Ball Lid
NI	211737	248562		Terminal

20	211881		Grommet, Cord Part Not Used-Gas Models Only
21	212073		LID (WHITE)
NI	212716		Bumper, Lid
25	213718		Plunger, Lid Switch
26	213720		Spring, Lid Switch
27	214437	215577	Bleach Inlet White
28	214804		Unbalance Lever
29	214805		Pin For Unbalance Lever
30	214813	Not Available	LEVER FOR LID SWITCH
31	214884	213501	Screw, No.6-20 X 1-1/8 Inch
32	214898		Cover For Lid Switch
33	214987		Moisture Barrier For Switch
34	215075		Fastener, Control Panel To Console
35	301548		Clamp, Ground Wire
36	311155		Ground Wire And Clamp
37	Y312140		Wire Connector
38	Y313559		Screw
NI	410635		Fastener
"	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx
"	911267		Screw, Pump Cover

