


Maytag A590 04 - CONTROL PANEL

Section: CONTROL PANEL

P/N 1600021

Models: A590 A884



11/91

10

Maytag [Residential Maytag A590 Washer Parts](#) Parts Diagram 04 - CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	206612		Not Available	WIRE HARNESS
2	206220		Not Available	WATER LEVEL SWITCH
3	211168	W10139210		Screw, 8-18 X 5/16
4	410296	596669		Clamp, Manifold
5	212942	22001619		Tube, Water Level Switch
6	206614			Fabric Control Switch
7	213117	67006908		Screw, Ice Rack
9	215211			Button For Switch
10	205410		Not Available	TIMER MOTOR 120-60
11	206606			Timer
12	215211			Button For Switch
13	206216			Water Temperature Switch
14	215213	214993		Button For Switch
"	215212			Button For Switch
15	214897			Pad, Control Panel
16	214872			Palnut, End Cap Note: Nut, Lamp Holder

17	210932		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
18	214816		End Cap F/Control Panel-RH
19	214894		Fastener, End Cap
20	213966	3400014	Screw
21	211065		Spring, Index Wheel
22	211605		Bezel, Timer Dial
23	215164	Not Available	CAP FOR KNOB
24	215162		Timer Knob
25	215161	22001571	Bezel, Timer Dial
26	214818		Back Up Plate
27	206605	Not Available	CONTROL PANEL
28	214815		End Cap F/Control Panel-LH

the laundry company[®]

the laundry company[®]

the laundry company[®]