



AGITATOR & ACCESSORIES



BRAKE & CLUTCH ASSEMBLY



[Maytag Residential Maytag A608S Washer Parts](#) Parts Diagram 01 - AGITATOR & ACCESSORIES

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	Y015494			Stop Ring-Agitator Shaft
2	203265			Lint Filter-Dispenser
3	203323	22004085		Large Agitator
4	212815		Not Available	DISPENSER CUP