



Maytag Residential Maytag A608S Washer Parts Parts Diagram 13 - TOP COVER UP
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	205529			Nut And Bolt Kit For Tub Clam
2	206154			Injector Tube With Seal
3	214493	59920-2		Rivet
4	215120			Seal For Injector Tube
5	200846			Clamp - Tub Cover
6	201765		Not Available	COVER, TUB
7	202515	596669		Clamp, Manifold
8	Y202734	215058		Pad, Cabinet Bumper
9	203156		Not Available	INNER TUB
10	203265			Lint Filter-Dispenser
11	203319	22203319		Cabinet
12	203323	22004085		Large Agitator
13	204445			Screw And Fastener Assembly
14	204968			Plunger And Bracket Assembly--W
15	205484			Tub, Outer Part Not Used
16	205160		Not Available	TOP COVER-WHITE

17	205161	489503	Clamp
18	211223		Bumper, Unbalance
19	211232		Seal, Tub Cover
20	211726		Hinge, Ball Lid
21	212073		LID (WHITE)
22	212716		Bumper, Lid
23	212815	Not Available	DISPENSER CUP
24	212937	Not Available	BARRIER, MOISTURE
"	212942	22001619	Tube, Water Level Switch
25	213013		Hose, Injector
26	213015		Nozzle, Injector
27	213718		Plunger, Lid Switch
28	213719	Not Available	LEVER, UNBALANCE
29	213720		Spring, Lid Switch
30	214135	Not Available	CLIP, FASTENER
31	214376	22002331	Spacer, Front Panel
32	214433		Tube, Inlet Part Not Used
33	214436		Gasket
34	214437	215577	Bleach Inlet White
35	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx

