



Maytag Residential Maytag A610 Washer Parts Parts Diagram 06 - TRANSMISSIONS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y014827			Washer-Center Shaft
2	Y014839			Collar-Drive Shaft
3	Y015629			Bolt, Grinding Chamber
4	015639			Dowel Pin
5	Y015902			Spring For Agitator
6	Y052740	62739		Nut, Lock
7	Y056080	6-0560800		Oil
8	200730	22002124		Shaft- Agi
9	200813		Not Available	GEAR CASE COVER ASSEMBLY
10	201463		Not Available	PITMAN WITH WRIST PIN
11	203193		Not Available	GEAR HOUSING W/STUDS & TUBE
12	203438	W10172457		Transmison
13	204967			Gear Kit-Power Fin Agitator
14	205811			Counterweight
15	210054			Pinion

16	210172		Lock Washer
17	210179		Retaining Ring
18	210183		Groove Pin
19	210286		Seal
20	210315		Pinion
21	210632	22210632	Gasket
22	210670		Segment
23	210690		Seal, Rubber
24	211089		Lug, Stop Pulley
25	211090	22003555	Washer, Stop Lug
26	211375	681582	Screw
27	211483	6-2114830	Washer- SP
28	211484		Washer, Lug
29	211486		Screw, 3/8-16 X 1/2 Inch
30	211487		Groov-Pin
31	213044		Shaft, Center
32	213068	204967	Gear Kit-Power Fin Agitator
33	214276	Not Available	WASHER FOR GEARS

