



Maytag A612 04 - CONTROL PANEL



Maytag Residential Maytag A612 Washer Parts Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	205033	22205033		Motor- Tim
2	206216			Water Temperature Switch
3	206217		Not Available	SPEED CONTROL SWITCH
4	206223	22206223		Switch- Wa
5	206225			Timer
8	206567		Not Available	CONTROL PANEL
10	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
11	211065			Spring, Index Wheel
12	211168	W10139210		Screw, 8-18 X 5/16
13	211605			Bezel, Timer Dial
14	213117	67006908		Screw, Ice Rack
15	213966	3400014		Screw
16	214809			Back Up Plate
17	214815			End Cap F/Control Panel-LH
18	214816			End Cap F/Control Panel-RH

19	214872		Panel, End Cap Note, Nut, Lamp Holder
20	214894		Fastener, End Cap
21	214897		Pad, Control Panel
22	215161	22001571	Bezel, Timer Dial
23	215162		Timer Knob
24	215164	Not Available	CAP FOR KNOB

