



Maytag A612S 04 - CONTROL PANEL



Maytag [Residential Maytag A612S Washer Parts](#) Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	205033	22205033		Motor- Tim
2	206216			Water Temperature Switch
3	206217		Not Available	SPEED CONTROL SWITCH
4	206223	22206223		Switch- Wa
6	206226		Not Available	SUDS SAVE SWITCH
7	206232			Timer
9	206568			Control Panel
10	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
11	211065			Spring, Index Wheel
12	211168	W10139210		Screw, 8-18 X 5/16
13	211605			Bezel, Timer Dial
14	213117	67006908		Screw, Ice Rack
15	213966	3400014		Screw
16	214809			Back Up Plate
17	214815			End Cap F/Control Panel-LH
18	214816			End Cap F/Control Panel-RH

19	214872		Palnut, End Cap Note: Nut, Lamp Holder
20	214894		Fastener, End Cap
21	214897		Pad, Control Panel
22	215161	22001571	Bezel, Timer Dial
23	215162		Timer Knob
24	215164	Not Available	CAP FOR KNOB

