



[Maytag Residential Maytag A700S Washer Parts Parts Diagram 02 - AGITATOR & ACCESSORIES](#)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	201379		Not Available	AGITATOR - BLACK
2	203057		Not Available	FILTER W/SEAL
3	211654		Not Available	O RING SEAL
4	211655		Not Available	SHROUD
5	211659		Not Available	SCREW, No.10-24 X 5/8 INCH
6	211667			Rubber Ring
7	212815		Not Available	DISPENSER CUP
8	0A4731		Not Available	SPLINE
9	038313	22038313		Wrench, Spanner
10	Y038315	038315		Tool