



[Maytag Residential Maytag A702 Washer Parts Parts Diagram 02 - AGITATOR & ACCESSORIES](#)  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	201379		Not Available	AGITATOR - BLACK
2	203320		Not Available	LINT FILTER - DISPENSER
3	211654		Not Available	O RING SEAL
4	211659		Not Available	SCREW, No.10-24 X 5/8 INCH
5	<a href="#">211667</a>			Rubber Ring
6	212815		Not Available	DISPENSER CUP
7	0A4731		Not Available	SPLINE
8	038313	<a href="#">22038313</a>		Wrench, Spanner
9	Y038315	<a href="#">038315</a>		Tool