



[Maytag Residential Maytag A702S Washer Parts Parts Diagram 01 - 230 VOLT, 50 CYCLE PARTS](#)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	202159		Not Available	MOTOR 240-50
2	Y202496			Pulley, Motor
3	211709		Not Available	MOTOR STOP
4	211948			V Belt, Drive Pulley
5	211451			Belt, Pump
6	201101			Capacitor
7	201621		Not Available	BALLAST
8	201110		Not Available	WIRE CONNECTOR
9	202630		Not Available	LAMP
10	201449		Not Available	WATER VALVE
11	201848			Solenoid 240-50
12	202998		Not Available	TIMER
13	203000		Not Available	TIMER
14	203083		Not Available	TIMER MOTOR 240-50