



Maytag Residential Maytag A702S Washer Parts Parts Diagram 09 - MOTOR MOUNT, BASE FRAME & CENTERING SPRS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200744	<a href="#">W10175939</a>		Bolt
2	200816	<a href="#">6-2008160</a>		Pulley- MO
3	<a href="#">201455</a>			Damper
4	<a href="#">201639</a>			Upper Motor Mount
5	201674		Not Available	LOWER MOTOR MOUNT---- NA
6	201698		Not Available	TUB BRACE
7	201727		Not Available	BASE FRAME WITH PADS
8	201807	<a href="#">12002353</a>		Motor-Drve
9	201956		Not Available	MOTOR CORD
10	202608	<a href="#">213737</a>		Shield, Motor
11	<a href="#">202718</a>			Springs, Tension
12	210186	<a href="#">3370225</a>		Screw
13	210587	<a href="#">W10116760</a>		Screw
14	<a href="#">211100</a>			Washer, Outer Tub
15	<a href="#">211124</a>			Part Not Used

16	<a href="#">211125</a>		V Belt, Drive Pulley
17	<a href="#">211155</a>		Washer
18	211294	<a href="#">90767</a>	Screw, 8A X 3/8 Hex Washer Head Tapping
19	<a href="#">211335</a>		Damper Pad - Felt
20	<a href="#">211944</a>		Eyebolts
21	<a href="#">211949</a>		Nut, Adjustment Eyebolt
22	204998	<a href="#">205000</a>	Roller And Spring Kit 4+Spr
23	<a href="#">211953</a>		Centering Spring
24	212026	Not Available	CORD HOLDER IN BASE FRAME
25	212142	Not Available	BRACKET -MOTOR SHIELD
26	<a href="#">Y310376</a>		Clip, Door Switch Harness
27	Y311426	<a href="#">3400029</a>	Nut, Adapter Plate
28	<a href="#">Y015627</a>		Screw- Hex
29	<a href="#">Y052734</a>		Nut, Carrage Bolts And Bracket
30	<a href="#">Y052785</a>		Nut, Brace To Damper
31	<a href="#">Y053241</a>		Set Screw, Motor Pulley
32	Y054866	<a href="#">486009</a>	Lockwasher
33	<a href="#">Y055978</a>		Rubber Adhesive, 2 Oz Tube
34	<a href="#">Y055980</a>		Hi-Temp Adhesive, 2 Oz Tube
35	<a href="#">Y056016</a>		Center Seal Grease

