

Maytag A702S 13 - WATER VALVE ASSEMBLY



[Maytag Residential Maytag A702S Washer Parts](#) Parts Diagram 13 - WATER VALVE ASSEMBLY
[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	200975		Not Available	DIAPHRAGM
2	200977			Solenoid For Water Valve
3	201018		Not Available	BODY FOR VALVE-NYLON
4	201163			Water Valve
5	210186	3370225		Screw
6	210429	96160		Screen
7	210452		Not Available	SCREW, No.10 X 15/32 INCH
8	210464		Not Available	CLIP, GROUND
9	211348		Not Available	GASKET
10	211350		Not Available	SCREW, No.8 X 1/2 INCH
11	211351			Spring For Plunger
12	211352		Not Available	PLUNGER
13	211353		Not Available	WASHER
14	211354		Not Available	FLOW WASHER
15	211356		Not Available	RUBBER WASHER
16	211357		Not Available	GASKET

17	211358	Not Available	SPACER
18	211359	Not Available	MOUNTING BRACKET
19	211360	Not Available	COVER PLATE
20	211361	Not Available	RETAINER
21	211362	Not Available	OUTLET RETAINER
22	211363	Not Available	SOLENOID GUIDE
23	211376	Not Available	SPRING
24	211377	Not Available	THERMAL ELEMENT
25	211378	Not Available	RETAINER
26	211505	Not Available	BRACKET
27	211714	Not Available	SCREW, SELF-TAPPING
28	211715	Not Available	OUTLET
29	212276	W10116760	Screw

the laundry company[®]

the laundry company[®]

the laundry company[®]