


Maytag A810 05 - TOP COVER, CONSOLE & LID SWITCH



Maytag Residential Maytag A810 Washer Parts Parts Diagram 05 - TOP COVER, CONSOLE & LID SWITCH
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y201808			Converter
2	204445			Screw And Fastener Assembly
3	204968			Plunger And Bracket Assembly--W
4	205056	204590		Cord, Power
5	205415	279347		Switch-Lid
6	205537			Top Cover-White
8	205635			Console
11	205820		Not Available	MAIN WIRE HARNESS
12	210186	3370225		Screw
13	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
14	211500			Washer, Bracket To Top Cover
15	211726			Hinge, Ball Lid
16	211737	248562		Terminal
17	211881			Grommet, Cord Part Not Used-Gas Models Only

18	212073		LID (WHITE)
20	212716		Bumper, Lid
21	213718		Plunger, Lid Switch
22	213720		Spring, Lid Switch
23	214436		Gasket
NI	214437	215577	Bleach Inlet White
25	214804		Unbalance Lever
26	214805		Pin For Unbalance Lever
27	214813	Not Available	LEVER FOR LID SWITCH
28	214884	213501	Screw, No.6-20 X 1-1/8 Inch
29	214898		Cover For Lid Switch
30	214987		Moisture Barrier For Switch
31	215075		Fastener, Control Panel To Console
32	301548		Clamp, Ground Wire
33	311155		Ground Wire And Clamp
34	Y312140		Wire Connector
35	Y313559		Screw
36	410635		Fastener
37	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx
38	911267		Screw, Pump Cover

