


Maytag A8520 04 - CONTROL PANEL

SECTION: CONTROL PANEL
MODEL: A8520



Issue Date: 4/90

10

Maytag [Residential Maytag A8520 Washer Parts](#) Parts Diagram 04 - CONTROL PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	212942	22001619		Tube, Water Level Switch
2	214809			Back Up Plate
3	215821		Not Available	CAP, KNOB
4	410296	596669		Clamp, Manifold
5	207603		Not Available	CONTROL PANEL
"	208118		Not Available	FACIA A8520
6	214897			Pad, Control Panel
7	207215		Not Available	END CAP LH
8	207216		Not Available	END CAP RH
9	214894			Fastener, End Cap
10	207360			Infinite Level Press Switch
11	214872			Palnut, End Cap Note: Nut, Lamp Holder
12	211605			Bezel, Timer Dial
13	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
14	211168	W10139210		Screw, 8-18 X 5/16

15	213117	67006908	Screw, Ice Rack
16	213966	3400014	Screw
17	211065		Spring, Index Wheel
18	207377		Not Available TIMER
"	207376	22207376	Timer
19	215827		Not Available TIMER DIAL SKIRT
20	215828		Knob, Timer
21	205033	22205033	Motor- Tim
22	207368		Not Available TEMP CONTROL SWITCH - 3 BUTTON
"	207367		Not Available TEMP CONTROL SWITCH - 4 BUTTON
23	207383		Wire Harness
"	207382		Wire Harness

the laundry company[®]

the laundry company[®]

the laundry company[®]