



[Maytag Residential Maytag A906 Washer Parts](#) Parts Diagram 06 - ELECTRICAL COMPONENTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200862		Not Available	BALLAST
2	<a href="#">200863</a>			Fluorescent Lamp
3	<a href="#">201423</a>			Receptacle
4	<a href="#">201838</a>			Starter Socket
5	201840	<a href="#">92790</a>		Starter
6	202807		Not Available	RECEPT FOR FLUORESCENT LAMP
7	203170		Not Available	FABRIC CONTROL SWITCH
8	<a href="#">203368</a>			Lamp Socket And Seal
9	204230		Not Available	FABRIC CONTROL SWITCH
10	<a href="#">204590</a>			Cord, Power
11	204701		Not Available	BUTTON KIT
12	210186	<a href="#">3370225</a>		Screw
13	210186	<a href="#">3370225</a>		Screw
14	211003		Not Available	BRACKET
15	211017	<a href="#">31001575</a>		Bulb, Cylinder Light
16	<a href="#">211252</a>			Screw, Ground Wire

17	211294	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
18	<a href="#">211410</a>		Screw, HeX Head No.8 X 3/8 Inch
19	211737	<a href="#">248562</a>	Terminal
20	211809	<a href="#">Y310376</a>	Clip, Door Switch Harness
21	<a href="#">211881</a>		Grommet, Cord Part Not Used-Gas Models Only
22	211967	<a href="#">211410</a>	Screw, HeX Head No.8 X 3/8 Inch
23	212220	<a href="#">213501</a>	Screw, No.6-20 X 1-1/8 Inch
24	212266	Not Available	SPRING-LIGHT BARRIER UNDER BUT
25	213006	Not Available	BRACKET
26	213008	Not Available	BRACKET
27	213012	Not Available	BRACKET FOR LAMP SOCKET
28	<a href="#">213323</a>		Fastener, Exhaust Duct Kit
29	213368	Not Available	DELICATE BUTTON
30	213369	Not Available	WOOL BUTTON
31	213370	Not Available	PERMANENT PRESS BUTTON
32	213371	Not Available	FULL WHITE LOAD BUTTON
33	213372	Not Available	PARTIAL WHITE LOAD BUTTON
34	213373	Not Available	FULL COLORED LOAD BUTTON
35	213374	Not Available	PARTIAL COLORED BUTTON
36	213375	Not Available	BRIGHT COLORS BUTTON
37	213376	Not Available	RINSE BUTTON
38	213377	Not Available	SPIN DRY BUTTON
39	213667	<a href="#">22003298</a>	Retainer, Wire
40	<a href="#">301548</a>		Clamp, Ground Wire
41	303846	<a href="#">22003781</a>	Screw, Ground Strap
42	310744	Not Available	SCREW-LAMP RECEPTACLE TO BRACK
43	<a href="#">311155</a>		Ground Wire And Clamp
44	Y313262	<a href="#">W10116752</a>	Retainer-

