

Maytag A906 08 - FRONT VIEW



[Maytag Residential Maytag A906 Washer Parts](#) Parts Diagram 08 - FRONT VIEW
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|------------------------|--------------------------|---------------|-----------------------------|
| 1 | 203170 | | Not Available | FABRIC CONTROL SWITCH |
| 2 | 203173 | | Not Available | TOP COVER-WHITE |
| 3 | 203319 | 22203319 | | Cabinet |
| 4 | 204230 | | Not Available | FABRIC CONTROL SWITCH |
| 5 | 204439 | | | Screw And Fstner Assembly |
| 6 | 204445 | | | Screw And Fastener Assembly |
| 7 | 204701 | | Not Available | BUTTON KIT |
| 8 | 210385 | | | Lock Nut For Adjustable Leg |
| 9 | 210684 | | | Foot, Adjustable Leg |
| 10 | 211252 | | | Screw, Ground Wire |
| 11 | 211726 | | | Hinge, Ball Lid |
| 12 | 212073 | | | LID (WHITE) |
| 13 | 212716 | | | Bumper, Lid |
| 14 | 212982 | 22001650 | | Fastener, Spring |
| 15 | 212991 | | Not Available | CONTROL PANEL |
| 16 | 212998 | | Not Available | PANEL, FRONT (WHT) |

| | | | |
|----|------------------------|--------------------------|--------------------------------|
| 17 | 213001 | Not Available | TRIM STRIP |
| 18 | 213007 | | Xfor Cabinet See Cabinet, Back |
| 19 | 213021 | Not Available | GLASS PANEL F/CONTROL PANEL |
| 20 | 213368 | Not Available | DELICATE BUTTON |
| 21 | 213369 | Not Available | WOOL BUTTON |
| 22 | 213370 | Not Available | PERMANENT PRESS BUTTON |
| 23 | 213371 | Not Available | FULL WHITE LOAD BUTTON |
| 24 | 213372 | Not Available | PARTIAL WHITE LOAD BUTTON |
| 25 | 213373 | Not Available | FULL COLORED LOAD BUTTON |
| 26 | 213374 | Not Available | PARTIAL COLORED BUTTON |
| 27 | 211375 | 681582 | Screw |
| 28 | 213376 | Not Available | RINSE BUTTON |
| 29 | 213377 | Not Available | SPIN DRY BUTTON |
| 30 | Y302699 | 22003428 | Leg, Adjustable |

