


Maytag AAV4200AGW 08 - TRANSMISSION (SERIES 17)



Maytag Residential Maytag AAV4200AGW Washer Parts Parts Diagram 08 - TRANSMISSION (SERIES 17)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7941			"O" Ring, Agrtr Drive Shaft
2	21001065			Screw, No.10-24 x .50 Hxnibhd
3	12001797	12002213		Thrust Bearing Kit
4	LA-2007	12002213		Thrust Bearing Kit
5	21001533	35-5655-1		Seal
6	35-2132			Washer, 1.25ODX.530IDX.032
"	35-2082			Washer, 1.25ODX.530IDX.062
7	21001868	W10219156		Tub Seal
8	25-7854			Ring, Retaining
9	21001867	35-6615		Ht TranS S
10	35-2018	35-6918		Stator, Brake
11	21001161	21002026		Snubber
12	21001511	12001562		Bearing Assembly
"	35-2205			Bearing, Spin
13	21001518			Support, Tub
14	21001532			Brace, Tub

15	21001858		Screw 5/16-18 x 1/2
16	21001163		Housing, Suspension
17	35-2017		Retainer, Brake Spring
18	21001647	21001910	Spring, Brake
19	25-7930	21001858	Screw 5/16-18 x 1/2
20	21001509		Screw, High Performance Plastic
21	35-2948	35-6714	Brake Roto
22	12500036	12002213	Thrust Bearing Kit
23	35-2010	207843	Lip Seal Repair Kit

